



Bass Guitar Practice Amp

Pathfinder Bass 10

Owner's Manual

Welcome!

Congratulations on your purchase of the VOX Pathfinder Bass 10 amplifier! Please read this manual thoroughly to learn how to use your new amplifier properly so that it will provide you with many years of reliable operation.

Caution: Adjust the volume level carefully. If you set the volume too high, your hearing may be damaged by the loud sound output. It is especially important to adjust the level appropriately when you are using headphones.

Top Panel

1. **INPUT jack**
Plug your bass guitar into this jack.

2. DRIVE control

This control enables you to adjust the overall distortion amount.
Turn the Drive control clockwise to increase distortion.

3. BRIGHT switch

Turn this switch on to create a bright and edgy sound by adding harmonics to the high frequency range.



4. TREBLE control

This control enables you to adjust the tone in the high frequency range.

5. BASS control

This control enables you to adjust the tone in the low frequency range.

6. VOLUME control

This master volume control enables you to adjust the overall sound level.

7. PHONES/LINEOUT jack

Use this jack to connect headphones or other devices.

Note: While this jack is being used, the internal speaker will be muted.

8. POWER switch

This switch turns the power to the amplifier on and off.

The indicator lights up when the power to the unit is turned on.

Specifications

Dimensions (W x D x H): 380 x 170 x 277 (mm) / 14.96 x 6.69 x 10.91 (inches) (including the projection)

Weight: 5.6kg / 12.35lb.

Output Power: 10 Watts RMS

Speaker: VOX Bulldog 5" x 2 (4 ohms)

Input: INPUT jack

Output: PHONES/LINEOUT jack

Controls: DRIVE, TREBLE, BASS, VOLUME, BRIGHT switch

* Specifications and appearance are subject to change without notice for improvement.

* All product names and company names are the trademarks or registered trademarks of their respective owners.

IMPORTANT SAFETY INSTRUCTIONS


- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Mains powered apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. (for USA and Canada)
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Turning off the power switch does not completely isolate this product from the power line so remove the plug from the socket if not using it for extended periods of time.
- Install this product near the wall socket and keep the power plug easily accessible.
- **WARNING:** This apparatus shall be connected to a mains socket outlet with a protective earthing connection.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not install this equipment on the far position from wall outlet and/or convenience receptacle.
- Do not install this equipment in a confined space such as a box for the conveyance or similar unit.
- Excessive sound pressure from earphones and headphones can cause hearing loss.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

WARNING:


TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
AVERTISSEMENT:
RISQUE DE CHOC ELECTRIQUE—NE PAS OUVRIR.
注意 感電の恐れあり、キャビネットをあけるな



The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

Notice regarding disposal (EU only)

When this "crossed-out wheeled bin" symbol is displayed on the product, owner's manual, battery, or battery package, it signifies that when you wish to dispose of this product, manual, package or battery you must do so in an approved manner. Do not discard this product, manual, package or battery along with ordinary household waste. Disposing in the correct manner will prevent harm to human health and potential damage to the environment. Since the correct method of disposal will depend on the applicable laws and regulations in your locality, please contact your local administrative body for details. If the battery contains heavy metals in excess of the regulated amount, a chemical symbol is displayed below the "crossed-out wheeled bin" symbol on the battery or battery package.

IMPORTANT NOTICE TO CONSUMERS

This product has been manufactured according to strict specifications and voltage requirements that are applicable in the country in which it is intended that this product should be used. If you have purchased this product via the internet, through mail order, and/or via a telephone sale, you must verify that this product is intended to be used in the country in which you reside.
WARNING: Use of this product in any country other than that for which it is intended could be dangerous and could invalidate the manufacturer's or distributor's warranty. Please also retain your receipt as proof of purchase otherwise your product may be disqualified from the manufacturer's or distributor's warranty.



VOX AMPLIFICATION LTD. 9 Newmarket Court, Kingston, Milton Keynes, MK10 0AU, UK

© 2009 VOX AMPLIFICATION LTD.

www.voxamps.com